

ElitePlank

LUXURY VINYL PLANKS

INSTALLATION INSTRUCTIONS

- All installations of Ozflor LVT product must be carried out in accordance to AS 1884:2012 “Floorcoverings – Resilient sheet & tiles- Installation practices” and in accordance to the manufacturer’s instructions.
- LVT flooring MUST be allowed to acclimatise to the temperature and humidity of the room for not less than 24 hours. Preferred room temperature 18-24°C.
- Moisture content and PH levels of the subfloor must comply with the relevant Australian Standards.
- After installation the same approximate temperature should be maintained for 48 hours.
- Spread the cartons out during acclimatisation, avoid double stacking of cartons.
- High/low traffic and commercial areas should be installed on UZIN KE 2000S hard set adhesive using a V1 notched trowel and rolled with a 34kg roller.
- Areas subject to intense heat from direct sunlight should be installed on UZIN KR430 PU adhesive.
- Windows should be covered for 48 hours during and after installation.
- Always check planks for possible defects such as chips and colour or gloss level variations under good light.
- It is recommended to use planks from the same batch as variation in colour or gloss level can occur from one batch to another.
- It is advisable to use planks from multiple boxes during installation.